

# Reliably Improve Placing Quality at the Changeover Level

# **IH1**

## Inspection system

- □ Operators can easily change a placing module to an inspection module
- □ Possible to inspect for foreign objects, missing parts, polarity, upside-down parts, and placing deviations
- Support high quality placing through cooperation with Fujitrax Adviser



Controller operation panel





Inspection head

#### **IH1Basic Specifications**

Applicable modules	NXT II (M3 II Note1, M6 II)
Inspection area (for one area)	36.4 mm x 26.7 mm
Number of inspection sequences per panel	0603 (0201) to 26 x 26 mm
Possible inspection height	From -2 mm to +10 mm (for placing deviations, +3 mm or less)
Premounted parts height (upper surface)	20 mm
Inspection speed	650 msec per area
Possible conveyance PCB size	Depends on the conveyor type
Possible fiducial mark reading area	X-direction: Up to 212 mm (M3 II), up to 534 mm (M6 II) Y-direction: Up to 610 mm (excluding clamping dead space)
Possible inspection area	X-direction: Up to 240 mm (M3 II), up to 534 mm (M6 II) Y-direction: Up to 610 mm (excluding clamping dead space)
Inspection sequence quantity	Up to 4000 sequences per PCB
Option	Support for automatic backup pins

Notes

1.Support for M3 II modules is under development.

### FUJI MACHINE MFG. CO., LTD.

19 Chausuyama Yamamachi Chiryu-shi, Aichi-ken 472-8686 Japan Tel: +81-566-81-2110 Fax: +81-566-83-1140



<sup>•</sup>The contents of this catalog are subject to change without notice.

Contact Fuji or a Fuji representative before transporting this product to a foreign location within your company or selling it to a third party within your country or a different country.