

---

## DEK USER MANUAL

---

### CONTENTS

MANUAL INFORMATION  
MANUAL ISSUE STATE  
DEK WORLDWIDE  
SALES AND SUPPORT

### CHAPTER 1 MACHINE PROGRAMMING

INTRODUCTION .....	1.1
STAGE 1 - POWER UP AND LOG ON .....	1.2
STAGE 2A - LOAD A PRODUCT FILE .....	1.5
STAGE 2B - LOAD A PRODUCT FILE .....	1.6
STAGE 2C - LOAD A PRODUCT FILE .....	1.7
STAGE 3 - EDIT A PRODUCT FILE .....	1.19
STAGE 4A - FIT SQUEEGEES .....	1.21
STAGE 4B - PROFLOW SETUP .....	1.25
STAGE 5 - LOADING A SCREEN .....	1.26
STAGE 6A - MAGNETIC PILLARS TOOLING .....	1.27
STAGE 6B - VACUUM TOOLING .....	1.34
STAGE 6C - DEDICATED TOOLING .....	1.40
STAGE 6D - MULTIFLEX TOOLING .....	1.46
STAGE 6E - FORMFLEX TOOLING .....	1.52
STAGE 6F - AUTOFLEX TOOLING .....	1.59
STAGE 7 - VISION SYSTEM SETUP .....	1.66
STAGE 8 - PRINT IN STEP MODE .....	1.80
STAGE 9 - 2DI SETUP .....	1.84
STAGE 10 - PRINT IN RUN MODE .....	1.85
MENU PARAMETERS .....	1.89
SPC CONFIGURATION .....	1.113
STATUS PAGE .....	1.121

### CHAPTER 2 SET PREFERENCES

INTRODUCTION .....	2.1
PREFERENCES .....	2.2

### CHAPTER 3 HOST COMMUNICATIONS

COMMS PROTOCOL OPTIONS .....	3.1
IP ADDRESS CONFIGURATION .....	3.3
HOST COMMS .....	3.6

### CHAPTER 4 ERROR MESSAGES

INTRODUCTION .....	4.1
ERROR RECOVERY .....	4.2
ERROR MESSAGE LISTING .....	4.3

**CHAPTER 5 DIAGNOSTICS**

INTRODUCTION .....	5.1
SYSTEM .....	5.2
PRINT HEAD .....	5.9
PRINT CARRIAGE .....	5.10
PROFLOW .....	5.12
SQUEEGEE .....	5.14
CAMERA AXES .....	5.16
RAIL SYSTEM .....	5.19
PASTE DISPENSE SYSTEM .....	5.21
SCREEN ALIGNMENT .....	5.22
SCREEN CHANGE .....	5.24
SCREEN CLEANER .....	5.26
RISING TABLE .....	5.28
MULTI INTERFACE UNIT .....	5.30
AUTOFLEX TOOLING (STANDARD) .....	5.31

**CHAPTER 6 MONITOR**

INTRODUCTION .....	6.1
LOG ON/OFF .....	6.2
HOST COMMS .....	6.3
CLEAR BATCH .....	6.4
BATCH LIMIT .....	6.5
PERFORM DISPLAY .....	6.6
EVENT DISPLAY .....	6.8
SYSTEM DISABLE .....	6.9

**CHAPTER 7 HOUSE KEEPING**

INTRODUCTION .....	7.1
SET DATE .....	7.2
SET TIME .....	7.3
PRINT DATA .....	7.4
COPY DATA .....	7.6
DELETE DATA .....	7.9
MANAGEMENT INFORMATION VIEWER .....	7.13
RECOVERY PROCEDURE .....	7.22
FEATURE LICENSING .....	7.25

**CHAPTER 8 2D INSPECTION**

MODULE OVERVIEW .....	8.1
2D INSPECTION SETUP .....	8.14
SETUP TIPS .....	8.36
OPTIONS AFTER AN INSPECTION ALARM .....	8.37
MENU PARAMETERS .....	8.39

**CHAPTER 9 CONSUMABLE REPLENISHMENTS**

INTRODUCTION .....	9.1
PASTE LOADING .....	9.2
BLUE UNDERSCREEN CLEANER .....	9.15
VORTEX UNDERSCREEN CLEANER .....	9.28
SQUEEGEES .....	9.38
PROFLOW .....	9.40